v1.1

Monta

Power management for your EV charger

Integration guide - Monta

TABLE OF CONTENTS

English 1

Svenska 2

English

Before you start:

A Monitor must be installed and configured to measure total consumption.

Follow these steps to integrate with Monta:

1

Get Monta ID

In the Monta portal you need to locate the “Load Balancing” section under “Site Details”. **You need to copy the entire "Site Identifier" number to then be entered into the Enegic app**.



Monta portal

2

In the Enegic app, go to **Settings, Licenses**.

Scan the QR code on the included integration license.

3



Go to **Settings, Reporters** and **Add new Reporter**.

4



Select **Monta** as the type of reporter from the list.

5



Enter an appropriate name such as “Monta charge control”.

Copy the Monta “Site Identifier” number from the Monta portal and paste into the Enegic app in the ID field.

6



Ensure the correct Enegic monitor is selected as total consumption measurement.

Then press **Save**.

7

Enegic Monitor is now integrated with Monta

The charging box(es) in the Monta installation you have integrated with now retrieve power values from Enegic, which enables a safe and efficient power output.

Svenska

Innan du sätter igång:

En Monitor ska vara installerad och konfigurerad för mätning av totalförbrukning.

Följ dessa steg för att integrera med Monta:

1

Hämta Monta-ID

I Monta-portalen behöver du leta reda på “Load Balancing”-sektionen under “Site Details”. **Sedan behöver du kopiera hela “Site Identifier”-numret för att därefter klistra in i Enegic-appen.**



Monta-portalen

2

I Enegic-appen, gå till **Inställningar**, **Licenser.**

Skanna QR-koden på den medföljande integrationslicensen.

3



Gå till **Inställningar**, **Rapportörer** och **Lägg till ny rapportör**.

4



Välj **Monta** som typ av rapportör från listan.

5



Sätt ett lämpligt namn för rapportören.

Kopiera Monta “Site Identifier”- numret från Monta-portalen och klistra in i Enegic-appen i ID-fältet.

6



Kontrollera att rätt Enegic Monitor-enhet är angiven som mätenhet för totalförbrukning.

Tryck sedan på **Spara**.

7

Nu är Enegic Monitor integrerad med Monta

Laddboxen/laddboxarna i Monta-installationen du integrerat med hämtar nu effektvärden från Enegic vilket möjliggör ett säkert och effektivt effektuttag.